

PX-3SBK 内蔵音色リスト

No.	音色グループ名	グループ内 音色No.	音色名	使用DSPアルゴリズム／備考
1	PIANO	001	GRAND PIANO 1	Equalizer
2	PIANO	002	GRAND PIANO 2	-
3	PIANO	003	ROCK PIANO	-
4	PIANO	004	MELLOW PIANO	Equalizer
5	PIANO	005	BRIGHT PIANO	Equalizer
6	PIANO	006	MONO PIANO 1	-
7	PIANO	007	MONO PIANO 2	-
8	PIANO	008	LA PIANO	Equalizer
9	PIANO	009	COMP.PIANO	Compressor
10	PIANO	010	DANCE PIANO	Equalizer
11	PIANO	011	STRINGS PIANO	Enhancer
12	PIANO	012	PIANO PAD	Enhancer
13	PIANO	013	HONKY-TONK	-
14	PIANO	014	OCTAVE PIANO	-
15	PIANO	015	HARPSICHORD	-
16	PIANO	016	COUPLED HARPSICHORD	-
17	ELEC PIANO 1	001	ELEC.PIANO 1	Stereo Phaser
18	ELEC PIANO 1	002	ELEC.PIANO PURE	-
19	ELEC PIANO 1	003	ELEC.PIANO 2	3-Phase Chorus
20	ELEC PIANO 1	004	DYNO ELEC.PIANO	-
21	ELEC PIANO 1	005	60'S E.PIANO	-
22	ELEC PIANO 1	006	PHASER EP	Stereo Phaser
23	ELEC PIANO 1	007	TREMOLO EP	Phaser - Auto Pan
24	ELEC PIANO 1	008	COMP.EP	Compressor
25	ELEC PIANO 1	009	WAH EP	Auto Wah
26	ELEC PIANO 1	010	PHASER 60'S EP	Stereo Phaser
27	ELEC PIANO 1	011	TREMOLO 60'S EP	Auto Pan
28	ELEC PIANO 1	012	STRINGS EP	-
29	ELEC PIANO 2	001	FM E.PIANO 1	-
30	ELEC PIANO 2	002	FM E.PIANO 2	-
31	ELEC PIANO 2	003	CHORUS EP	Phaser - Chorus
32	ELEC PIANO 2	004	MELLOW E.PIANO	Stereo Phaser
33	ELEC PIANO 2	005	POP ELEC.PIANO	Enhancer
34	ELEC PIANO 2	006	SYNTH-STR.EP	-
35	ELEC PIANO 2	007	ELEC.GRAND 1	-
36	ELEC PIANO 2	008	ELEC.GRAND 2	Stereo Phaser
37	CLAVI/VIBES	001	CLAVI 1	-
38	CLAVI/VIBES	002	CLAVI 2	-
39	CLAVI/VIBES	003	WAH CLAVI	Auto Wah
40	CLAVI/VIBES	004	PHASER CLAVI	Stereo Phaser
41	CLAVI/VIBES	005	COMP.CLAVI	Compressor
42	CLAVI/VIBES	006	VIBRAPHONE	-
43	CLAVI/VIBES	007	TREMOLO VIBES	Tremolo
44	CLAVI/VIBES	008	MARIMBA	-
45	ORGAN	001	JAZZ ORGAN 1	Rotary
46	ORGAN	002	JAZZ ORGAN 2	Rotary
47	ORGAN	003	ROCK ORGAN 1	Drive Rotary
48	ORGAN	004	ROCK ORGAN 2	Rotary
49	ORGAN	005	PERC.ORGAN 1	Rotary
50	ORGAN	006	PERC.ORGAN 2	Rotary
51	ORGAN	007	PERC.ORGAN 3	Rotary
52	ORGAN	008	DRAWBAR ORGAN 1	Rotary

No.	音色グループ名	グループ内 音色No.	音色名	使用DSPアルゴリズム／備考
53	ORGAN	009	DRAWBAR ORGAN 2	Rotary
54	ORGAN	010	DRAWBAR ORGAN 3	Rotary
55	ORGAN	011	ELEC.ORGAN 1	Rotary
56	ORGAN	012	ELEC.ORGAN 2	Rotary
57	ORGAN	013	ELEC.ORGAN 3	Rotary
58	ORGAN	014	70'S ORGAN	Rotary
59	ORGAN	015	OVERDRIVE ORGAN	Distortion
60	ORGAN	016	TREMOLO ORGAN	Auto Pan
61	ORGAN	017	CHURCH ORGAN	-
62	ORGAN	018	CHAPEL ORGAN	-
63	STRINGS/ENSEMBLE	001	STEREO STRINGS	Early Reflection
64	STRINGS/ENSEMBLE	002	STRINGS	-
65	STRINGS/ENSEMBLE	003	WARM STRINGS	-
66	STRINGS/ENSEMBLE	004	STRING ENSEMBLE	-
67	STRINGS/ENSEMBLE	005	SLOW STRINGS	-
68	STRINGS/ENSEMBLE	006	SYNTH-STRINGS 1	Equalizer
69	STRINGS/ENSEMBLE	007	SYNTH-STRINGS 2	Stereo Phaser
70	STRINGS/ENSEMBLE	008	70'S SYNTH-STR.	-
71	STRINGS/ENSEMBLE	009	80'S SYNTH-STR.	-
72	STRINGS/ENSEMBLE	010	VIOLIN SECTION	-
73	STRINGS/ENSEMBLE	011	ORCHESTRA PAD	Early Reflection
74	STRINGS/ENSEMBLE	012	CHOIR	-
75	STRINGS/ENSEMBLE	013	SYNTH-VOICE	-
76	STRINGS/ENSEMBLE	014	VOICE PAD	Phaser
77	STRINGS/ENSEMBLE	015	WARM PAD	-
78	STRINGS/ENSEMBLE	016	WARM VOX	-
79	STRINGS/ENSEMBLE	017	FANTASY	-
80	STRINGS/ENSEMBLE	018	NEW AGE	Equalizer
81	STRINGS/ENSEMBLE	019	POLYSYNTH PAD	-
82	STRINGS/ENSEMBLE	020	ATMOSPHERE PAD	-
83	GUITAR/BASS	001	STEEL STR.GUITAR 1	-
84	GUITAR/BASS	002	NYLON STR.GUITAR	-
85	GUITAR/BASS	003	12 STR.GUITAR	-
86	GUITAR/BASS	004	JAZZ GUITAR	Compressor - Chorus
87	GUITAR/BASS	005	CLEAN GUITAR	Compressor - Phaser
88	GUITAR/BASS	006	DISTORTION GT	Compressor - Distortion - Auto Pan
89	GUITAR/BASS	007	ACOUSTIC BASS	-
90	GUITAR/BASS	008	RIDE BASS	-
91	GUITAR/BASS	009	FINGERED BASS	-
92	GUITAR/BASS	010	FRETLESS BASS	-
93	OTHERS/GM	001	STEREO BRASS	Early Reflection
94	OTHERS/GM	002	BRASS SECTION	-
95	OTHERS/GM	003	SYNTH-BRASS 1	-
96	OTHERS/GM	004	SYNTH-BRASS 2	-
97	OTHERS/GM	005	80'S SYNTH-BRASS	-
98	OTHERS/GM	006	SQUARE LEAD 1	Early Reflection
99	OTHERS/GM	007	SQUARE LEAD 2	-
100	OTHERS/GM	008	SAW LEAD 1	Early Reflection
101	OTHERS/GM	009	SAW LEAD 2	-
102	OTHERS/GM	010	SAW LEAD 3	-
103	OTHERS/GM	011	MELLOW SAW LEAD	-
104	OTHERS/GM	012	PULSE LEAD 1	-
105	OTHERS/GM	013	PULSE LEAD 2	-
106	OTHERS/GM	014	SINE LEAD	-
107	OTHERS/GM	015	ALTO SAX	-

No.	音色グループ名	グループ内 音色No.	音色名	使用DSPアルゴリズム／備考
108	OTHERS/GM	016	TENOR SAX	-
109	OTHERS/GM	017	BREATHY ALTO SAX	-
110	OTHERS/GM	018	CLARINET	-
111	OTHERS/GM	019	FLUTE	-
112	OTHERS/GM	020	TRUMPET	Enhancer
113	OTHERS/GM	021	GM PIANO 1	-
114	OTHERS/GM	022	GM PIANO 2	-
115	OTHERS/GM	023	GM PIANO 3	-
116	OTHERS/GM	024	GM HONKY-TONK	-
117	OTHERS/GM	025	GM E.PIANO 1	-
118	OTHERS/GM	026	GM E.PIANO 2	-
119	OTHERS/GM	027	GM HARPSICHORD	-
120	OTHERS/GM	028	GM CLAVI	-
121	OTHERS/GM	029	GM CELESTA	-
122	OTHERS/GM	030	GM GLOCKENSPIEL	-
123	OTHERS/GM	031	GM MUSIC BOX	-
124	OTHERS/GM	032	GM VIBRAPHONE	-
125	OTHERS/GM	033	GM MARIMBA	-
126	OTHERS/GM	034	GM XYLOPHONE	-
127	OTHERS/GM	035	GM TUBULAR BELL	-
128	OTHERS/GM	036	GM DULCIMER	-
129	OTHERS/GM	037	GM ORGAN 1	-
130	OTHERS/GM	038	GM ORGAN 2	-
131	OTHERS/GM	039	GM ORGAN 3	-
132	OTHERS/GM	040	GM PIPE ORGAN	-
133	OTHERS/GM	041	GM REED ORGAN	-
134	OTHERS/GM	042	GM ACCORDION	-
135	OTHERS/GM	043	GM HARMONICA	-
136	OTHERS/GM	044	GM BANDONEON	-
137	OTHERS/GM	045	GM NYLON STR.GUITAR	-
138	OTHERS/GM	046	GM STEEL STR.GUITAR	-
139	OTHERS/GM	047	GM JAZZ GUITAR	-
140	OTHERS/GM	048	GM CLEAN GUITAR	-
141	OTHERS/GM	049	GM MUTE GUITAR	-
142	OTHERS/GM	050	GM OVERDRIVE GT	-
143	OTHERS/GM	051	GM DISTORTION GT	-
144	OTHERS/GM	052	GM GT HARMONICS	-
145	OTHERS/GM	053	GM ACOUSTIC BASS	-
146	OTHERS/GM	054	GM FINGERED BASS	-
147	OTHERS/GM	055	GM PICKED BASS	-
148	OTHERS/GM	056	GM FRETLESS BASS	-
149	OTHERS/GM	057	GM SLAP BASS 1	-
150	OTHERS/GM	058	GM SLAP BASS 2	-
151	OTHERS/GM	059	GM SYNTH-BASS 1	-
152	OTHERS/GM	060	GM SYNTH-BASS 2	-
153	OTHERS/GM	061	GM VIOLIN	-
154	OTHERS/GM	062	GM VIOLA	-
155	OTHERS/GM	063	GM CELLO	-
156	OTHERS/GM	064	GM CONTRABASS	-
157	OTHERS/GM	065	GM TREMOLO STRINGS	-
158	OTHERS/GM	066	GM PIZZICATO	-
159	OTHERS/GM	067	GM HARP	-
160	OTHERS/GM	068	GM TIMPANI	-
161	OTHERS/GM	069	GM STRINGS 1	-
162	OTHERS/GM	070	GM STRINGS 2	-

No.	音色グループ名	グループ内 音色No.	音色名	使用DSPアルゴリズム／備考
163	OTHERS/GM	071	GM SYNTH-STRINGS 1	-
164	OTHERS/GM	072	GM SYNTH-STRINGS 2	-
165	OTHERS/GM	073	GM CHOIR AAHS	-
166	OTHERS/GM	074	GM VOICE DOO	-
167	OTHERS/GM	075	GM SYNTH-VOICE	-
168	OTHERS/GM	076	GM ORCHESTRA HIT	-
169	OTHERS/GM	077	GM TRUMPET	-
170	OTHERS/GM	078	GM TROMBONE	-
171	OTHERS/GM	079	GM TUBA	-
172	OTHERS/GM	080	GM MUTE TRUMPET	-
173	OTHERS/GM	081	GM FRENCH HORN	-
174	OTHERS/GM	082	GM BRASS	-
175	OTHERS/GM	083	GM SYNTH-BRASS 1	-
176	OTHERS/GM	084	GM SYNTH-BRASS 2	-
177	OTHERS/GM	085	GM SOPRANO SAX	-
178	OTHERS/GM	086	GM ALTO SAX	-
179	OTHERS/GM	087	GM TENOR SAX	-
180	OTHERS/GM	088	GM BARITONE SAX	-
181	OTHERS/GM	089	GM OBOE	-
182	OTHERS/GM	090	GM ENGLISH HORN	-
183	OTHERS/GM	091	GM BASSOON	-
184	OTHERS/GM	092	GM CLARINET	-
185	OTHERS/GM	093	GM PICCOLO	-
186	OTHERS/GM	094	GM FLUTE	-
187	OTHERS/GM	095	GM RECORDER	-
188	OTHERS/GM	096	GM PAN FLUTE	-
189	OTHERS/GM	097	GM BOTTLE BLOW	-
190	OTHERS/GM	098	GM SHAKUHACHI	-
191	OTHERS/GM	099	GM WHISTLE	-
192	OTHERS/GM	100	GM OCARINA	-
193	OTHERS/GM	101	GM SQUARE LEAD	-
194	OTHERS/GM	102	GM SAW LEAD	-
195	OTHERS/GM	103	GM CALLIOPE	-
196	OTHERS/GM	104	GM CHIFF LEAD	-
197	OTHERS/GM	105	GM CHARANG	-
198	OTHERS/GM	106	GM VOICE LEAD	-
199	OTHERS/GM	107	GM FIFTH LEAD	-
200	OTHERS/GM	108	GM BASS+LEAD	-
201	OTHERS/GM	109	GM FANTASY	-
202	OTHERS/GM	110	GM WARM PAD	-
203	OTHERS/GM	111	GM POLYSYNTH	-
204	OTHERS/GM	112	GM SPACE CHOIR	-
205	OTHERS/GM	113	GM BOWED GLASS	-
206	OTHERS/GM	114	GM METAL PAD	-
207	OTHERS/GM	115	GM HALO PAD	-
208	OTHERS/GM	116	GM SWEEP PAD	-
209	OTHERS/GM	117	GM RAIN DROP	-
210	OTHERS/GM	118	GM SOUND TRACK	-
211	OTHERS/GM	119	GM CRYSTAL	-
212	OTHERS/GM	120	GM ATMOSPHERE	-
213	OTHERS/GM	121	GM BRIGHTNESS	-
214	OTHERS/GM	122	GM GOBLINS	-
215	OTHERS/GM	123	GM ECHOES	-
216	OTHERS/GM	124	GM SF	-
217	OTHERS/GM	125	GM SITAR	-

No.	音色グループ名	グループ内 音色No.	音色名	使用DSPアルゴリズム／備考
218	OTHERS/GM	126	GM BANJO	-
219	OTHERS/GM	127	GM SHAMISEN	-
220	OTHERS/GM	128	GM KOTO	-
221	OTHERS/GM	129	GM THUMB PIANO	-
222	OTHERS/GM	130	GM BAGPIPE	-
223	OTHERS/GM	131	GM FIDDLE	-
224	OTHERS/GM	132	GM SHANAI	-
225	OTHERS/GM	133	GM TINKLE BELL	-
226	OTHERS/GM	134	GM AGOGO	-
227	OTHERS/GM	135	GM STEEL DRUMS	-
228	OTHERS/GM	136	GM WOOD BLOCK	-
229	OTHERS/GM	137	GM TAIKO	-
230	OTHERS/GM	138	GM MELODIC TOM	-
231	OTHERS/GM	139	GM SYNTH-DRUM	-
232	OTHERS/GM	140	GM REVERSE CYMBAL	-
233	OTHERS/GM	141	GM GT FRET NOISE	-
234	OTHERS/GM	142	GM BREATH NOISE	-
235	OTHERS/GM	143	GM SEASHORE	-
236	OTHERS/GM	144	GM BIRD	-
237	OTHERS/GM	145	GM TELEPHONE	-
238	OTHERS/GM	146	GM HELICOPTER	-
239	OTHERS/GM	147	GM APPLAUSE	-
240	OTHERS/GM	148	GM GUNSHOT	-
241	OTHERS/GM	149	STANDARD SET 1	Drum Sets
242	OTHERS/GM	150	STANDARD SET 2	Drum Sets
243	OTHERS/GM	151	ROOM SET	Drum Sets
244	OTHERS/GM	152	POWER SET	Drum Sets
245	OTHERS/GM	153	ELECTRONIC SET	Drum Sets
246	OTHERS/GM	154	SYNTH SET 1	Drum Sets
247	OTHERS/GM	155	SYNTH SET 2	Drum Sets
248	OTHERS/GM	156	JAZZ SET	Drum Sets
249	OTHERS/GM	157	BRUSH SET	Drum Sets
250	OTHERS/GM	158	ORCHESTRA SET	Drum Sets

※ドラムセット音色（No.241～No.250）の鍵盤ごとの打楽器については、ドラム音色リストをご参照ください。

ドラム音色リスト

音名/ ノートナンバー	STANDARD SET 1	STANDARD SET 2	ROOM SET	POWER SET	ELECTRONIC SET	SYNTH SET 1	SYNTH SET 2	JAZZ SET	BRUSH SET	ORCHESTRA SET
E1 28	High Q	←	←	←	←	←	←	←	←	Closed Hi-Hat
F1 29	Slap	←	←	←	←	←	←	←	←	Pedal Hi-Hat
G1 31	Scratch Push	←	←	←	←	←	←	←	←	Open Hi-Hat
A1 33	Scratch Pull	←	←	←	←	←	←	←	←	Ride Cymbal 1
B1 35	Sticks	←	←	←	←	←	←	←	←	←
C2 36	Square Click	←	←	←	←	←	←	←	←	←
D2 38	Metronome Click	←	←	←	←	←	←	←	←	←
E2 40	Metronome Bell	←	←	←	←	←	←	←	←	←
F2 41	Standard1 Kick 2	Standard2 Kick 2	Room Kick 2	Power Kick 2	Elec. Kick 2	Synth1 Kick 2	Synth2 Kick 2	Jazz Kick 2	Jazz Kick 2	Jazz Kick 1
G2 43	Standard1 Kick 1	Standard2 Kick 1	Room Kick 1	Power Kick 1	Elec. Kick 1	Synth1 Kick 1	Synth2 Kick 1	Jazz Kick 1	Brush Kick	Concert BD
A2 45	Side Stick	←	←	←	←	Synth1 Rim Shot	Synth1 Rim Shot	←	Brush Side Stick	←
B2 47	Standard1 Snare 1	Standard2 Snare 1	Room Snare 1	Power Snare 1	Elec. Snare 1	Synth1 Snare 1	Synth2 Snare 1	Jazz Snare 1	Brush Snare 1	Concert SD
C3 49	Hand Clap	←	←	←	←	Synth1 Hand Clap	←	←	Brush Slap	Castanets
D3 50	Standard1 Snare 2	Standard2 Snare 2	Room Snare 2	Power Snare 2	Elec. Snare 2	Synth1 Snare 2	Synth2 Snare 2	Jazz Snare 2	Brush Snare 2	Concert SD
E3 51	Low Tom 2	←	Room Low Tom 2	Room Low Tom 2	Elec. Low Tom 2	Synth1 Low Tom 2	Synth2 Low Tom 2	←	←	Timpani F
F3 53	Closed Hi-Hat	Standard2 Closed Hi-Hat	←	←	←	Synth1 Closed Hi-Hat 1	Synth2 Closed Hi-Hat 1	←	←	Timpani F
G3 55	Low Tom 1	←	Room Low Tom 1	Room Low Tom 1	Elec. Low Tom 1	Synth1 Low Tom 1	Synth2 Low Tom 1	←	←	Timpani G
A3 57	Pedal Hi-Hat	Standard2 Pedal Hi-Hat	←	←	←	Synth1 Closed Hi-Hat 2	Synth2 Closed Hi-Hat 2	←	←	Timpani G
B3 59	Mid Tom 2	←	Room Mid Tom 2	Room Mid Tom 2	Elec. Mid Tom 2	Synth1 Mid Tom 2	Synth2 Mid Tom 2	←	←	Timpani A
C4 60	Open Hi-Hat	Standard2 Open Hi-Hat	←	←	←	Synth1 Open Hi-Hat	Synth2 Open Hi-Hat	←	←	Timpani A
D4 62	Mid Tom 1	←	Room Mid Tom 1	Room Mid Tom 1	Elec. Mid Tom 1	Synth1 Mid Tom 1	Synth2 Mid Tom 1	←	←	Timpani B
E4 64	High Tom 2	←	Room High Tom 2	Room High Tom 2	Elec. High Tom 2	Synth1 High Tom 2	Synth2 High Tom 2	←	←	Timpani c
F4 65	Crash Cymbal 1	←	←	←	←	Synth1 Crash Cymbal	←	←	Brush Crash Cymbal 1	Timpani c
G4 67	High Tom 1	←	Room High Tom 1	Room High Tom 1	Elec. High Tom 1	Synth1 High Tom 1	Synth2 High Tom 1	←	←	Timpani d
A4 69	Ride Cymbal 1	←	←	←	←	Synth1 Ride Cymbal	←	←	Brush Ride Cymbal 1	Timpani d
B4 71	Chinese Cymbal	←	←	←	Reverse Cymbal	←	←	←	←	Timpani e
C5 72	Ride Bell	←	←	←	←	←	←	←	Brush Ride Bell	Timpani e
D5 74	Tambourine	←	←	←	←	Synth1 Tambourine	←	←	Brush Tambourine	Timpani f
E5 76	Splash Cymbal	←	←	←	←	←	←	←	Brush Splash Cymbal	←
F5 77	Cowbell	←	←	←	←	Synth1 Cowbell	Synth1 Cowbell	←	←	←
G5 79	Crash Cymbal 2	←	←	←	←	←	←	←	Brush Crash Cymbal 2	Concert Cymbal 2
A5 81	Vibraslap	←	←	←	←	←	←	←	←	←
B5 83	Ride Cymbal 2	←	←	←	←	←	←	←	Brush Ride Cymbal 2	Concert Cymbal 1
C6 84	High Bongo	←	←	←	←	Synth1 High Bongo	←	←	←	←
D6 86	Low Bongo	←	←	←	←	Synth1 Low Bongo	←	←	←	←
E6 88	Mute High Conga	←	←	←	←	Synth1 Mute Hi Conga	←	←	←	←
F6 89	Open High Conga	←	←	←	←	Synth1 Open Hi Conga	←	←	←	←
G6 91	Open Low Conga	←	←	←	←	Synth1 Open Low Conga	←	←	←	←
A6 93	High Timbale	←	←	←	←	←	←	←	←	←
B6 95	Low Timbale	←	←	←	←	←	←	←	←	←
C7 97	High Agogo	←	←	←	←	←	←	←	←	←
D7 99	Low Agogo	←	←	←	←	←	←	←	←	←
E7 101	Cabasa	←	←	←	←	←	←	←	←	←
F7 103	Maracas	←	←	←	←	Synth1 Maracas	Synth1 Maracas	←	←	←
G7 105	Short High Whistle	←	←	←	←	←	←	←	←	←
A7 107	Long Low Whistle	←	←	←	←	←	←	←	←	←
B7 109	Short Guiro	←	←	←	←	←	←	←	←	←
C8 111	Long Guiro	←	←	←	←	←	←	←	←	←
D8 113	Claves	←	←	←	←	Synth1 Claves	Synth1 Claves	←	←	←
E8 115	High Wood Block	←	←	←	←	←	←	←	←	←
F8 117	Low Wood Block	←	←	←	←	←	←	←	←	←
G8 119	Mute Cuica	←	←	←	←	←	←	←	←	←
A8 121	Open Cuica	←	←	←	←	←	←	←	←	←
B8 123	Mute Triangle	←	←	←	←	←	←	←	←	←
C9 125	Open Triangle	←	←	←	←	←	←	←	←	←
D9 127	Shaker	←	←	←	←	←	←	←	←	←
E9 129	Jingle Bell	←	←	←	←	←	←	←	←	←
F9 131	Bell Tree	←	←	←	←	←	←	←	←	←
G9 133	Castanets	←	←	←	←	←	←	←	←	←
A9 135	Mute Surdo	←	←	←	←	←	←	←	←	←
B9 137	Open Surdo	←	←	←	←	←	←	←	←	←
C10 139	Applause 1	←	←	←	←	←	←	←	←	←
D10 141	Applause 2	←	←	←	←	←	←	←	←	←

※ “←” の鍵盤は、STANDARD SETと同じ音です。